



STARLINK | PERFORMANCE SETUP GUIDE







What's In The Box

Starlink Performance Dish





Advanced Power Supply

Starlink Performance
Cable25 m
(82 ft)Starlink Ethernet
Cable5 m
(16.4 ft)Starlink AC Power
Cable1.5 m
(4.9 ft)Starlink DC Power
Cable1.5 m
(4.9 ft)

1 | Download the Starlink App

Download the Starlink App and scan the QR code to step through the install process.





2 | Plug in Cables and Connect to Power

Align the Performance Connector end of the Starlink cable indicated by the red notch and plug into your Starlink by holding the end of the plug and firmly inserting into the dish.

Connect the other end of the Starlink cable to the power supply. Install either the AC (2A) or DC (2B) Power Cable into the power supply, depending on your power source, and plug into a power outlet. Ensure all cables are fully plugged in until the plug face is flush with the surface.

If needed, to remove the Starlink cable, rotate the collar counterclockwise and pull out to disconnect from your Starlink.




3 | Find Mounting Location and Align Starlink

Your Starlink needs a clear view of the sky so it can stay connected with satellites as they move overhead. Objects that obstruct the connection between your Starlink and the satellite, such as a tree branch, pole, or roof, will cause service interruptions. Use the obstruction tool in the App to ensure you have selected a suitable mounting location.

An alert on the App will show if you need to rotate Starlink to be properly aligned. Tap the alert to use the alignment tool.

Ensure to check for obstructions and your Starlink is properly aligned before permanently installing your Starlink.



4 | Connect Starlink

If using a Starlink Router, connect the Router to the Advanced Power Supply using the cable provided in the router kit. Step through the Starlink install process on the Starlink App. You can utilize the Starlink App to view statistics, access terminal settings and contact support.

If using a third party router, use the provided ethernet cable in the Performance Kit. After you have set up your 3rd party router and connected to Starlink with the WAN port, open the Starlink app. If the app says "Starlink unreachable", create a static route in your router configuration settings.

Please refer to your router's documentation for instructions on setting a static route.


Network destination: 192.168.100.0

Subnet Mask: 255.255.255.0

Gateway: 192.168.100.1

Interface: WAN


Note: These options may differ depending on your specific hardware and network configuration.



ADVANCED POWER SUPPLY UNIT

1 | Remove Mount


Remove the power supply from the mount by pulling and twisting the quick release pins in either direction. The pins will lock in place to allow for easy removal of the power supply.



2 | Mark Pilot Holes


Select a mount location no more than 1.5 m (5ft) away from your power source.

Mark the location of the four holes on your power supply mount using a pen or pencil.




3 | Drill the Pilot Holes

Drill the holes with a 8 mm (5/16 in) drill bit.



4 | Install Anchors and Mount


Push anchors into holes until flush with the wall. Place the wall mount over the anchors and screw the mount into the wall until securely attached.



5 | Plug In Cables and Install Power Supply

Plug in the Starlink, ethernet and AC or DC cables into the power supply by removing the waterproof plugs and ensure the cables are fully inserted. Slide the power supply into the mount, making sure both locking pins snap into place.

Finish installation by routing the Ethernet cable to your router install location, connect to router and plug in router and power supply into your power source.



INSTALLATION CONDITIONS

CAUTION! If you are uncomfortable with any part of the installation process, do not attempt - contact a professional to install your Starlink. Starlink is not responsible for injury or damage to property caused by the installation process.

Kit Installation for Use on Moving Vehicles.

CAUTION! Take extra care if installing a Starlink for being used on a moving vehicle or vessel. Ensure that the mount is installed firmly on a structurally sound, horizontal surface away from other equipment to give your Starlink a clear view of the sky. Equipment falling off the vehicle due to poor installation practices can cause serious accidents resulting in bodily injury, do not mount the Starlink on any vehicle or vessel if the mount structure is not stable, or if it cannot be properly secured as described in this guide. Ensure the installation on vehicle or vessel is compliant with local Department of Transportation or maritime regulations.

WARNING! Mounts are not designed for high winds, hurricane or tornado wind loads. Tethering should be used in all cases to prevent failure in an unexpected wind event. See installation instructions before connecting this equipment to the input supply.

WARNING! To avoid personal injury and/or damage to the property when drilling, take caution and follow basic safety procedures, including:

- Wear appropriate eye, hand, and face protection.
- Avoid studs, electrical wiring, and water lines when drilling. Drilling into any of these can lead to fire, shock, injury, or death.
- Drill at a slight downward angle from the home interior to the home exterior and thoroughly apply sealant. Improper drilling and sealing may lead to water and/or bug intrusion and/or damage.